Dockmaker.com

6’x14’ Float Section

For Non-commercial and Non-public Applications

To make a Gap Filler Strip Rip a 2x6 at 45 deg. (Length wise). Cross cut to the length of the gap leaving room for the Hinge Plate. Put the right angle edge flush with the deck surface.



Gap Filler Strip
Reduces space to 3/4“ - 1”
where sections join.

Floatation mounts
to bottom of frame
with Lag Kit #9278-6

INSTRUCTIONS

Typical framing to be of grade #1, P.T. min. with 2x6 for non-commercial, light load.
Add intermediate framing boards to improve load and duty capacity.
Typical decking to be 5/4x6 P.T. Or Cedar, materials that span up to 24“.
Use 3“ (10 penny) galvanized nails for assembly.
Decking to be cut 6’ flush to frame to prevent snagging with boats and gear.
Router along the ends of the deck boards with a 3/8“ radius to soften edges and reduce splinters.
Use typical 1/2“ spacing between deck boards to avoid leaf and other debris trapping.
For reinforcing butt joints that could pull apart at the nails, use the Corner Iron (#6027A) with

Lumber Requirements

4-14’ 2x Long Stringers
3-14’ 2x Long Sringers (for comp deck)
2-6’ 2x End Stringers
12 Lin Ft 2x blocking
28-5/4x6x6’ Deck Boards
Add 2x for Gap Filler Strips (See above desc.)

(The Hinge Plates type and placement listed here may vary from what is actually required to complete your overall dock plan.)

Parts List

2-#2304 12“x24”x36” Foam Filled Floats
4-#2305 12“x24”x48” Foam Filled Floats
6-#9278-6 Lag Kit for Foam Filled Floats
16-#6027A Corner Iron
4-#6010 Reinforced Hinge Plates
15-#9280 Bolt Kits
2-#9092 Hinge Bolt w/Nylock (to link up next section)
Add for cleats, bumpers and other accessories.



Disclaimer

Dockmaker and its proprietors shall not be held liable for the safety and performance of its designs. Before using any design, you are hereby advised to consult with an architect or public engineer licensed to perform services in the community where your dock project will be installed, along with code enforcement in said community. The project owner who uses Dockmaker plans and instructions accepts sole responsibility for the safety and overall performance of the designs.